

Dual Gauge Overhead T-Top Pod for G-Body



1. Start by removing the 4 screws on the factory T-Top trim using a Phillips head screwdriver.
2. Clean the surface of the factory trim with an alcohol prep pad to remove any dirt and grease.
3. Remove the backing from the included double-sided tap on the T-Top pod and secure to the factory trim.
4. Reinstall the trim and secure to the vehicle with the factory screws.
5. Follow the instructions included with each gauge to finalize the gauge installation process, it may be necessary to drill a hole in the factory trim to allow the wires to pass through.



INSTALLATION INSTRUCTIONS

856.768.8300 • Support@GlowShiftGauges.com

All GlowShift Products are subject to the GlowShift Limited Warranty. Please visit <https://www.glowshiftdirect.com/warranty-policies> to review complete Warranty, Terms, and Conditions.